



Xcorder





# **Buttons and symbols**









# Taking pictures



Select the «shutter» button once to enter the still image action menu. Press the «shutter» button again to take a picture.

# Recording video



Select the «record» button once to enter the recording action menu. Press the «record» button again to start a video recording. Hit the button a third time to stop.

# Transfering media files

## Method 1 (PC)



To transfer the media files wirelessly to your PC, you need to configure a shared folder on your PC. Please follow the instructions below.

### Pc:

- 1. Create a folder «pixavi» under c:/
- 2. Right click folder «pixavi» and select «sharing»
- 3. Click «share», type «everyone» and click «add»
- 4. Select read/write under permission level and click «ok»

## **Xcorder:**

- 1. Select «Sync» and then select «PC».
- 2. Connect your PC to the wireless network called «pixavi».
- 3. Select «Sync» to transfer the media files to your PC.

## Method 2 (WiDRIVE - USB)



WIDRIVE The Xcorder also supports transfer of media files to a wireless harddrive called WiDRIVE. This method enables you to access your media files via USB. Please follow the instructions below.

## **WIDRIVE:**

- 1. Remove the USB cable and press the powerbutton on top.
- 2. Wait until all active lights are green.

## **Xcorder:**

- 1 Select «Setup», «General» and make sure WiDRIVE is set to «ON» and press «OK».
- 2. From main menu select «Sync» and then select «WiDRIVE».
- 3. Select «Sync» to transfer the media files to your WiDRIVE.

When the sync operation is complete, just plug the WiDRIVE USB cable into your pc. All your files will appear under the folder named Public.

The WiDRIVE can be purchased as an accessory from Pixavi.

NOTE: Please remember to catalog the files located in the PC or WiDRIVE folder between each sync, as the process will potentially overwrite files from the previous sync session if these files share the same filename.





# Activating Image stabilization



Press the «mode» button and set the image stabilization to «On». Select «OK» to save setting.

## Change light sensitivity



Press the «mode» button and under light sensitivity select between Day, Normal MODE and Night mode. Select «OK» to save setting.

## Setting up Windows for network sharing

If you are having trouble with the PC sync process, it is likely that the Windows sharing options have not been properly set up. The following 4-step process decribes how to set up a Windows PC, so that the Xcorder can access the folder c:/pixavi we created during the PC sync chapter.

- 1. Click start-button and type "Sharing Center"
- 2. Click the "Network and Sharing Center" icon
- 3. Click "Change advanced sharing settings" in the left panel
- 4. Turn off "Password protected sharing" and click "Save Changes"

## **Complete product manual:**

The complete product manual for this product can be download here:

http://www.pixavi.com/support-pixavi-manuals.php

## **Software updates:**

Software updates for this product can be downloaded here:

http://www.pixavi.com/support-site-pixavi.php

### **Conformity:**

This device has been evaluated and found to conform to the European Directive 1999/5/EC. A letter of conformity for this product can be found here:

http://www.pixavi.com/support-site-pixavi.php (login: declaration / password: conformity)

#### **Warning:**

This is a class A product. In a domestic environment this product may cause radio interference, which may require the user to take adequate measures.

## **Important Radio frequency notifications:**

- •In case of using external third party antennas, the maximum gain allowed for an attached antenna is 5dBi.
- •Please note that certain limitations applies to the use of the WLAN radio of this product in France, Italy and Latvia.
- •Pixavi recommends to check with local authorities for the latest status of their national regulations for wireless LANs when selecting antennas and access points.

